

# PLI Support Guide: How to Start an RTK Survey - R10

Summary: This guide will show you how to start an RTK Survey with two R10 Receivers.

1. Click on the "General Survey" icon in Trimble Access.



2. Click on "Instrument."



#### Pittsburgh Office

85 11th Street

Ambridge, PA 15003

Ph: (724) 266-1600

Fax: (724) 266-8161

# **Columbus Office**

372 Morrison Rd., Suite D Columbus, OH 43213 Ph: (614) 759-1000 Fax: (614) 759-7059

### Cincinnati Office

820-B Lebanon Street Monroe, OH 45050 Ph: (513) 539-0022 Fax: (513) 539-0033

Akron Office

2567 S. Arlington Rd., Suite 5

Akron, OH 44319

Ph: (330) 633-4900

Fax: (330) 633-4999

### **WV Office**



Construction • Survey • GIS

Sales • Service • Rental • Training • Support

3. Click on "GNSS functions."

8	<b>≫</b> I	nstrument		-> -> ×			
4	<u>G</u> NS	S functions	>	<u>R</u> eceiver settings			
Satellites			eBubble options				
	<u>R</u> ec	eiver files		Navigate to point			
	<u>P</u> osi	ition		<u>C</u> amera			
	<u>R</u> ec	eiver status					
	<u>G</u> SM	l Status					
	n als	No surve	y PD(	OP:1.3			
В	аск			Next			

4. To properly set your base up, you want to position it over a known point that was shot with your VRS Survey Style. With your GNSS function in Base Mode (when base mode is highlighted orange) click "*Start Survey*."

Start base -> 🕗	? <b>—</b> ×
Point name: Code:	
?	15
Observation class:	
Antenna height (Uncorrected):	<u>A</u>
?	👗 ?
Measured to:	<u>M</u> ap
Bottom of quick release	Menu
Station index: Transmit Delay:	F <u>a</u> vorites
	S <u>w</u> itch to
No survey PDOP:1.2	
ESC	

### Pittsburgh Office

85 11th Street

Ambridge, PA 15003

Ph: (724) 266-1600

Fax: (724) 266-8161

# Columbus Office

372 Morrison Rd., Suite D Columbus, OH 43213 Ph: (614) 759-1000 Fax: (614) 759-7059

### Cincinnati Office

820-B Lebanon Street Monroe, OH 45050 Ph: (513) 539-0022 Fax: (513) 539-0033

### Akron Office

2567 S. Arlington Rd., Suite 5 Akron, OH 44319 Ph: (330) 633-4900 Fax: (330) 633-4999

# WV Office



5. For Point name, click the arrow off to the right of the text box and click "List." A list of the available points will show up. Make sure your Antenna height is set and click "Start."

📎 Start base 🚽 🔊 🖉	? — ×
Point name: Point name: Point name: Wildcard search Key in	<ul> <li>▶ 70%</li> <li>▶ 90%</li> <li>▲ 17</li> </ul>
Autonomous	2
Antenna height (Uncorrected): ?	2 ?
Measured to:	<u>M</u> ap
Bottom of quick release	Menu
Station index: Transmit Delay:	F <u>a</u> vorites
<u>0 ms</u> ▼	S <u>w</u> itch to
No survey PDOP:1.2	
Esc	Enter

6. Click on the point that you want to use as your "Occupy Point."

<b>(2)</b>	Select a po	int		->	Ø [	? _ ×
Poir	Name	Cod	de			■♪ 70% ■♪ 90%
	⊞ 306	Cor	ntrol F	Point		<u> </u>
Obs						<b>10</b>
Au .	ununuu.					<u> </u>
Anter	nna height (Un	corrected):			· · · · · · · · · · · · · · · · · · ·	A-R 3
?						👗 ?
Meas	ured to:					<u>M</u> ap
Bott	tom of quick	release	•			Menu
Statio	on index:	Trans	mit Del	ay:	-	E
21		0 ms	s 🔻	]		ravorites
		J L		J		S <u>w</u> itch to
	N	survey PE	DOP:1.	2		
Esc	Filter F	leview Pa	ge 🛉	Page 🖊		Accept

### Pittsburgh Office

85 11th Street

Ambridge, PA 15003

Ph: (724) 266-1600

Fax: (724) 266-8161

# **Columbus Office**

372 Morrison Rd., Suite D Columbus, OH 43213 Ph: (614) 759-1000 Fax: (614) 759-7059

### Cincinnati Office

820-B Lebanon Street Monroe, OH 45050 Ph: (513) 539-0022 Fax: (513) 539-0033

Akron Office

2567 S. Arlington Rd., Suite 5 Akron, OH 44319 Ph: (330) 633-4900 Fax: (330) 633-4999

# WV Office



Construction • Survey • GIS

Sales • Service • Rental • Training • Support

7. Make sure your "Antenna height" is set and click "Start."

	۵ ک	Start b	ase			[	- <b>&gt;</b> 0	? – ×	
	Point n	ame:			Code:			■ 70%	
	306				Contro	ol Point		90%	
	Observ	ation cla	iss:					18	
	Auto	nomou	S					A I	
1	Antenn	ia heigh	t (Unco	orrect	ted).				
×	6.562	?sft						A 6.562	
	Measur	ed to:						<u>M</u> ap	
	Βοπο	om or q	иіск	relea				M <u>e</u> nu	
	Station	index:		1	I ransmi	t Delay:		F <u>a</u> vorites	
	21				0 1115			Switch to	
			No	surv	/ey PDO	P:1.2			
	Esc							Start	
	<b>&gt;</b>		_				- <b>)</b> ()	? – ×	
						[	-) ()	? — ×	
						[	- <b>&gt;</b> ()	<ul> <li>? - ×</li> <li>70%</li> <li>90%</li> <li>√2 15</li> </ul>	
							-) ()	? — × 70% 90% √ 15	
		Base	start	ted			- <b>)</b> ()	? – × 70% 90% 315	
		Base Base	e start	ted			-) 0	? – × 70% 90% 15	
		Base Base	: start	ted			- <b>)</b> ()	<ul> <li>? — ×</li> <li>70%</li> <li>90%</li> <li>415</li> <li>6.562</li> </ul>	
		Base	: start	ted			-) ()	? – × 70% 90% 15 6.562 Map	
		Base Base	startes startes	ted d			- <b>)</b> ()	<ul> <li>? — ×</li> <li>70%</li> <li>90%</li> <li>✓ 15</li> <li>6.562</li> <li>Map</li> <li>1enu</li> </ul>	
		Base	: start started OK	ted d				? – × 70% 90% 15 6.562 Map <u>1enu</u> Favorites	
		Base	starte starte	ted d				<ul> <li>? — ×</li> <li>90%</li> <li>90%</li> <li>15</li> <li>6.562</li> <li>Map</li> <li>4enu</li> <li>Favorites</li> <li>Switch to</li> </ul>	
	₿ Fsc	Base Base	e start started QK Bas	ted d	rvey PD0	DP:1.2		? — X 70% 90% 15 6.562 Map Aenu Favorites Switch to	
	Esc	Base	e start started OK Bas	ted d	rvey PDC	DP:1.2		<ul> <li>? — ×</li> <li>70%</li> <li>90%</li> <li>15</li> </ul> 6.562 Map Aenu Favorites Switch to Enter	

### Pittsburgh Office

85 11th Street

Ambridge, PA 15003

Ph: (724) 266-1600

Fax: (724) 266-8161

# Columbus Office

372 Morrison Rd., Suite D Columbus, OH 43213 Ph: (614) 759-1000 Fax: (614) 759-7059

### **Cincinnati Office**

820-B Lebanon Street Monroe, OH 45050 Ph: (513) 539-0022 Fax: (513) 539-0033 Akron Office

2567 S. Arlington Rd., Suite 5 Akron, OH 44319 Ph: (330) 633-4900 Fax: (330) 633-4999

# WV Office



8. Now click on "Rover Mode." It will then connect to your R10 Rover Receiver.



9. You will know Rover Mode is selected if after you click on it the "Rover Mode" button is highlighted orange.



### Pittsburgh Office

85 11th Street

Ambridge, PA 15003

Ph: (724) 266-1600

Fax: (724) 266-8161

# **Columbus Office**

372 Morrison Rd., Suite D Columbus, OH 43213 Ph: (614) 759-1000 Fax: (614) 759-7059

### **Cincinnati Office**

820-B Lebanon Street Monroe, OH 45050 Ph: (513) 539-0022 Fax: (513) 539-0033

Akron Office

2567 S. Arlington Rd., Suite 5 Akron, OH 44319 Ph: (330) 633-4900 Fax: (330) 633-4999

# **WV Office**



10. Click "Start Survey." You will see a list of available Survey Styles. Choose your RTK Survey Style.



### **Pittsburgh Office**

85 11<sup>th</sup> Street

Ambridge, PA 15003

Ph: (724) 266-1600

Fax: (724) 266-8161

# **Columbus Office**

372 Morrison Rd., Suite D Columbus, OH 43213 Ph: (614) 759-1000 Fax: (614) 759-7059

# **Cincinnati Office**

820-B Lebanon Street Monroe, OH 45050 Ph: (513) 539-0022 Fax: (513) 539-0033

### Akron Office

2567 S. Arlington Rd., Suite 5 Akron, OH 44319 Ph: (330) 633-4900 Fax: (330) 633-4999

# **WV Office**



11. After your Survey has started, you will see your reliability percentage, this is the communication rating from Radio to Reciever as to how many packets are being recieved. This should say "100%." Click "Accept" and then "Enter."



### Pittsburgh Office

85 11th Street

Ambridge, PA 15003

Ph: (724) 266-1600

Fax: (724) 266-8161

# **Columbus Office**

372 Morrison Rd., Suite D Columbus, OH 43213 Ph: (614) 759-1000 Fax: (614) 759-7059

### **Cincinnati Office**

820-B Lebanon Street Monroe, OH 45050 Ph: (513) 539-0022 Fax: (513) 539-0033

### Akron Office

2567 S. Arlington Rd., Suite 5 Akron, OH 44319 Ph: (330) 633-4900 Fax: (330) 633-4999

# **WV** Office





12. You are now back to the main "General Survey" screen. You're all set!

Now you can hit the Trimble Shortcut Key on your Keypad and go back into Access and enter Utility Survey.

### **Pittsburgh Office**

85 11<sup>th</sup> Street

Ambridge, PA 15003

Ph: (724) 266-1600

Fax: (724) 266-8161

# **Columbus Office**

372 Morrison Rd., Suite D Columbus, OH 43213 Ph: (614) 759-1000 Fax: (614) 759-7059

# Cincinnati Office

820-B Lebanon Street Monroe, OH 45050 Ph: (513) 539-0022 Fax: (513) 539-0033

Akron Office

2567 S. Arlington Rd., Suite 5 Akron, OH 44319 Ph: (330) 633-4900 Fax: (330) 633-4999

**WV Office**